


Spare Part Breakdown Part Number for model HIT RC16-BN and RC16-B6D



Part No.	Discription
1	Main base
2	Knife
3	Knife
4	Upper base
5	Pipe lower
6	Pipe upper
7	Rubber grip
8	Bolt center
10	Bolt to knife
11	Nut to No.17
13	Roller body
14	Pin
15	Roller
16	Nut to No.10
17	Cape Screw
18	Roller pin
19	Bender roller
20	Snap Ring
22	Nut to No.8
23	Roller pin
24	Cape Screw
25	Lock washer to No.8
27	Washer to No.8
28	Handle pin
29	Snap Ring