



PT1324

Digital Thermometer

Instructions for use:

1. Clean the probe with warm water.
2. Turn on the power with "ON/OFF" button.
3. Select the unit with "°C/°F" button.
4. Hold the head of the thermometer and insert the head of the probe into the middle part of object to be measured. It is strongly suggested to insert the probe through the loop on the sheath and hold the sheath to measure hot water, oil and other hot objects.
5. After 5 seconds, read the data on LCD.
6. Turn off the power with "ON/OFF" button, otherwise the power will be turned off automatically when no buttons are pressed in for 45 minutes.

Important:

1. Never clean the thermometer head by immersing it in any liquid.
2. Never let the thermometer head contact hot oil or other hot object if temperature over 158°F (70°C).
3. Do not drop or knock thermometer.

Specifications:

Range: -50 ~ 200°C (-58 ~ 392°F)

Accuracy: +/- 1.8°F (32~212°F)

+/- 1°C (0~100°C)

Increments: 0.1°F ▪ 0.1°C

