



PT1730

Water Pressure Gauge

Instructions for use:

To test the water pressure to a property:

1. Locate a hose tap, turn it off, and remove any existing attachments.
2. Screw the brass nut and tail onto the hose tap using the supplied bush for 3/4" threads if required.
3. Make sure that no other water is currently being used on the property.
4. Slowly turn on the hose tap (to avoid a pressure surge). Check that there is no leakage at the nut and tail connection. Tighten, if needed.
5. Read the recorded pressure on the gauge.
6. Turn off the hose tap and remove the nut and tail.

Note: Pressures recorded will vary according to the time of day and usage of water in the nearby area.

Features:

- Will test up to 2500kPa
- No hoses, fits directly to tap.
- Comes with a bush adaptor.
- For 1/2 inch and 3/4 inch taps.
- Glycerin filled gauge protects workings.
- Dual scale reads in both KPa and PSI

